



LEDLENSER KIDBEAM4


KIDBEAM4



1 Clip



2 Battery Replacement



3 Default Operation

Note: Remove Foil Before First Use

Off Off Low Power

